


RX-V567/HTR-5063 HDMI Blu-ray/DVD, Cable/SAT and Component Video Game Console Hookup Diagram



Notes:
The Component Input AV #1 will need to be associated to the Audio #1 input. Please see page 2 of this document for detailed instructions on setting that feature up.

How do I connect up my **Game Console (Example: Nintendo Wii)** game system using the **Component Video/Stereo Analog** cables to my **RX-Vx67**, or **HTR-x063 Yamaha A/V Receiver**?

1. Connect **Component Video Cables** from **Nintendo Wii** to **AV1** input on **Receiver**.
2. Connect **Stereo/Analog Red & White** audio cables from **Nintendo Wii** to **Audio 1** on **Receiver**.
3. Walk up to the front of the receiver and select **AV1** on the **Receiver Remote Control**.
4. Press the **Option** button on **Receiver Remote Control** and **Volume Trim** appear on the front display of **Receiver**.
5. Using **Arrow** down button on **Receiver Remote Control**, scroll down to **Audio In Menu**.
6. Press the **Enter** button on the **Receiver Remote Control** to enter **Audio In Menu**.
7. Use **Arrow** button to the **Right** to move to **Audio 1** selection.
8. Press **Option** button to exit **Option Menu**.
9. When **AV1** is selected on the **Receiver** it will look to **Audio 1** for the audio signal.