

Available functions for each instrument

Updated: 2024/4

Functions			Instruments										
			TransAcoustic Piano		Silent Piano		AvantGrand				Standalone		
			TA2	TA3 TC3	SC2 SH2	SC3 SH3	NU1X	NU1XA	N1X	N3X	from installing the app to connecting a supported instrument		
Piano Room	Piano Room	Lid Position	yes	yes	yes	yes	yes	yes	yes	yes	-		
		Brightness	-	-	-	-	-	yes	-	-	-	-	
		Touch Curve	-	-	-	-	-	yes	-	-	-	-	
		Environment	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		VRM	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Damper Resonance	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Damper Noise	-	yes	-	yes	-	yes	-	-	-	-	
		String Resonance	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Duplex Scale Resonance	yes	yes	yes	yes	yes	yes	-	-	-	-	
		Body Resonance	yes	yes	yes	yes	yes	yes	-	-	-	-	
		Grand Expression Modeling	-	yes	-	yes	-	yes	-	-	-	-	
		Key Off Sampling	yes	-	yes	-	-	-	-	-	-	-	
		Half Pedal Point	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
Each Key Setting	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
Voice	Voice Select Layer	Left, Split Point	-	-	-	-	-	-	-	-	-		
		Voice Setting	Octave	-	-	-	-	-	-	-	-	-	
			Mixer	Volume	-	-	-	-	-	-	-	-	-
				Pan	-	-	-	-	-	-	-	-	-
		Reverb	-	-	-	-	-	-	-	-			
Style			yes	yes	yes	yes	yes	yes	yes	yes	-		
Song	Playback, FF, Rewind	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song - Preset)	yes	yes	yes	yes	yes	yes	yes	yes	-		
		(MIDI Song - User)	yes	yes	yes	yes	yes	yes	yes	yes	-		
	AB Repeat	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	-	-	-	-	-	yes	-	-	-		
	Guide (MIDI Song)	-	-	-	-	-	-	-	-	-	-		
	Volume	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	-	yes	-	-	-		
	Tempo	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes (*1)	yes (*1)	yes (*1)	yes (*1)	yes (*1)	yes	yes	yes	-		
	Transpose	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	-	yes	-	yes	-		
	Part (MIDI Song)	Right, Left	-	yes	-	yes	-	yes	-	-	-		
		Backing	-	-	-	-	-	yes	-	-	-		
	PDF Score	Viewer	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Playback	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Guide	-	-	-	-	-	-	-	-	-		
	Score Screen		yes	yes	yes	yes	yes	yes	yes	yes	-		
	Chord Screen		yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Lyrics Screen		yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Audio Song Analysis	Audio to Score	-	-	-	-	-	-	-	-	-		
		Chord Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Chord Edit		yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Copy, Delete, Undo	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Song Setting	Arrangement (Audio Song)	Audio to Score Setting	-	-	-	-	-	-	-	-	-	
			Backing	-	-	-	-	-	-	-	-	-	
			Melody Suppressor	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Playback	Stream Lights / Guide Lamp	-	-	-	-	-	-	-	-	-	
			Guide Type (MIDI Song)	-	-	-	-	-	-	-	-	-	
			Quick Start (MIDI Song)	-	-	-	-	-	yes	-	-	-	
MIDI Part Channel (MIDI Song)			-	-	-	-	-	-	-	-	-		
Score		yes	yes	yes	yes	yes	yes	yes	yes	yes			
Chord		yes	yes	yes	yes	yes	yes	yes	yes	yes			
Lyrics		yes	yes	yes	yes	yes	yes	yes	yes	yes			
Mixer	-	-	-	-	-	-	-	-	-				
Song Edit	Quantize (MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	-			
	Delete, Mix, Setup (MIDI Song)	-	-	-	-	-	-	-	-	-			
	Trimming (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	-			
Recording	Audio Recording (*2)	yes	yes	yes	yes	yes	yes	yes	yes	-			
	Audio Overdub Recording (*2)	yes	yes	yes	yes	yes	yes	yes	yes	-			
	MIDI Recording	yes	yes	yes	yes	yes	yes	yes	yes	-			
	MIDI Multitrack Recording	-	-	-	-	-	-	-	-	-			
Metronome	Metronome	yes	yes	yes	yes	yes	yes	yes	yes	-			
	Rhythm	-	yes	-	yes	-	-	-	-	-			
	Bass On/Off	-	yes	-	yes	-	-	-	-	-			
Balance			-	yes	-	yes	-	yes	-	-			
Registration Memory			yes	yes	yes	yes	yes	yes	yes	yes			
Utility	Transpose	Master Tune	yes	yes	yes	yes	yes	yes	yes	yes			
		Scale Tune	yes	yes	yes	yes	yes	yes	yes	yes			
	Keyboard Setting	Touch Curve	yes	yes	yes	yes	yes	yes	yes	yes			
		TRS	-	-	-	-	-	-	-	yes	-		
	Pedal Setting	Function Assign	-	-	-	-	-	-	-	-			
		Score Page Turning	-	-	-	-	yes	yes	yes	yes			
		Half Pedal Point	yes	yes	yes	yes	yes	yes	yes	-			
	AUX Pedal Polarity	-	-	-	-	-	-	-	-	-			
	Mic Setting	Vocal Harmony	-	-	-	-	-	-	-	-			
	Master EQ	Sound Setting	Brilliance	yes	yes	yes	yes	-	yes	-	-		
			Speaker Setting	-	-	-	-	-	yes	-	-		
			Binaural / Stereophonic Optimizer	Binaural	Binaural	Binaural	Binaural	Binaural	Binaural	Binaural	Binaural		
			Lid Position / TA Mode Tone Control	yes	yes	-	-	-	-	-	-		
			IAC (Intelligent Acoustic Control)	yes	yes	-	yes	yes	yes	yes	yes		
			Sound Boost	-	-	-	-	-	-	-	-		
			Wall EQ	-	-	-	-	-	-	-	-		
			AUX Out Volume	-	-	-	-	-	-	-	-		
			Volume Limiter	-	-	-	-	-	-	-	-		
			Limit Point	-	-	-	-	-	-	-	-		
	AUX In Noise Gate	yes	yes	yes	yes	yes	-	yes	yes				
System	Version, Language, Manual, FAQ	yes	yes	yes	yes	yes	yes	yes	yes				
	Audio Rec Format	yes	yes	yes	yes	yes	yes	yes	-				
	Auto Power Off	yes	yes	yes	yes	yes	yes	yes	yes				
	Firmware Version, Firmware Update	-	-	-	-	-	-	-	-				
	Factory Reset	yes	yes	yes	yes	yes	yes	yes	yes				
	Backup, Restore	yes	yes	yes	yes	yes	yes	yes	yes				
Demo			-	-	-	-	-	-	-	-			
Connection	Wi-Fi (*3)	UD-WL01	yes	yes	yes	yes	yes	yes	yes	-			
	Bluetooth (*2) (*3)	Built-in	-	yes	-	yes	-	yes	-	-			
		UD-BT01 (for iPhone / iPad)	-	-	-	-	-	-	-	-			
	USB cable (for iPhone / iPad with Lightning terminal)	Lighting - USB cable	-	-	-	-	-	-	-	-			
		Lightning to USB Camera Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes			
		Lighting to USB Camera Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-			
		USB-C - Lightning cable	-	-	-	-	-	-	-	-			
	USB cable (for iPhone / iPad with Type-C terminal)	USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes			
		USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-			
	USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	-				
USB cable (for Android devices with Type-C Terminal)	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes				
	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-				
	USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	-				

(*1) Tempo can be changed while song is playing.

(*2) During Bluetooth connection, audio recording function is not available.

(*3) Availability varies by area.

Available functions for each instrument

Updated: 2024/4

Functions		Instruments															
		Clavinova CLP						Clavinova CSP			Clavinova CVP		SCLP			Standalone	
		CLP-635 CLP-645 CLP-665GP CLP-675	CLP-685 CLP-695GP	CLP-725	CLP-735	CLP-745 CLP-765GP CLP-775	CLP-785 CLP-795GP	CSP-150 CSP-170	CSP-255 CSP-275 CSP-295 CSP-295GP	CVP-805 CVP-809	CVP-905 CVP-909	SCLP-6350 SCLP-6450	SCLP-7350	SCLP-7450	from installing the app to connecting a supported instrument		
Piano Room	Piano Room Setting	Lid Position	yes	yes	-	yes	yes	yes	yes	-	-	yes	yes	yes	-		
		Brightness	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Touch Curve	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Environment	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		VRM	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Damper Resonance	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Damper Noise	-	-	-	yes	yes	yes	-	yes	-	-	-	yes	yes	yes	-
		String Resonance	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Duplex Scale Resonance	yes	yes	-	yes	yes	yes	-	yes	-	-	yes	yes	yes	-	
		Body Resonance	yes	yes	-	yes	yes	yes	-	yes	-	-	yes	yes	yes	-	
		Grand Expression Modeling	-	-	yes	yes	yes	yes	-	yes	-	-	-	yes	yes	-	
		Key Off Sampling	yes	yes	-	-	-	-	yes	-	-	-	yes	-	-	-	
		Half Pedal Point	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
Each Key Setting	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
Voice	Voice Select Layer	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
	Left, Split Point	yes	yes	yes	yes	yes	yes	yes	yes	-	-	-	-	-	-		
	Voice Setting	Octave	yes	yes	yes	yes	yes	yes	yes	yes	-	-	-	-	-	-	
		Volume	yes	yes	yes	yes	yes	yes	yes	yes	-	-	-	-	-	-	
		Mixer	yes	yes	-	yes	yes	yes	yes	yes	-	-	-	-	-	-	
		Reverb	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
	Style	-	-	-	-	-	-	yes	yes	-	-	-	-	-	-		
	Song	Playback, FF, Rewind	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
(MIDI Song - Preset)			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
(MIDI Song - User)			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
AB Repeat		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Guide (MIDI Song)		(Audio Song)	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Volume		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Tempo		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes (*1)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Transpose		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Part (MIDI Song)		Right, Left	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Backing	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
PDF Score		Viewer	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Playback Guide	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Score Screen		-	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
Chord Screen		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Lyrics Screen		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Audio Song Analysis		Audio to Score	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
		Chord Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Chord Edit		Copy, Delete, Undo	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Arrangement (Audio Song)	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
Song Setting	Playback	Stream Lights / Guide Lamp	-	-	-	-	-	yes	yes	yes	yes	-	-	-			
		Guide Type (MIDI Song)	-	-	-	-	-	yes	yes	yes	yes	-	-	-			
		Quick Start (MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes			
	Score	MIDI Part Channel (MIDI Song)	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
		Chord	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Lyrics	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Mixer	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
	Song Edit	Quantize (MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Delete, Mix, Setup (MIDI Song)	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-		
		Trimming (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Recording	Audio Recording (*2)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes			
	Audio Overdub Recording (*2)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes			
	MIDI Recording	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes			
	MIDI Multitrack Recording	-	-	-	-	-	-	yes	yes	yes	yes	-	-	-			
Metronome	Metronome	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes			
	Rhythm	yes	yes	-	yes	yes	yes	-	-	-	-	yes	yes	yes			
Balance	Bass On/Off	-	-	-	yes	yes	yes	-	-	-	-	-	yes	yes			
	Registration Memory	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes			
Utility	Transpose	Master Tune	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes			
		Scale Tune	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes			
	Keyboard Setting	Touch Curve	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes			
		TRS	-	-	-	-	-	-	-	-	-	-	-	-			
	Pedal Setting	Function Assign	-	-	-	-	-	-	yes	yes	-	-	-	-			
		Score Page Turning	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes			
		Half Pedal Point	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes			
	AUX Pedal Polarity	-	yes	-	-	-	yes	yes	yes	-	-	-	-	-			
	Mic Setting	Vocal Harmony	-	-	-	-	-	-	yes	yes	-	-	-	-			
	Master EQ	Sound Setting	Brilliance	-	-	-	yes	yes	yes	-	-	-	-	yes	yes		
			Speaker Setting	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes		
			Binaural / Stereophonic Optimizer	Binaural	Binaural	Stereophonic Optimizer	Binaural	Binaural	Binaural	Binaural	Binaural	-	-	Binaural	Binaural		
			Lid Position / TA Mode Tone Control	-	-	-	-	-	-	-	-	-	-	-	-		
			IAC (Intelligent Acoustic Control)	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes		
			Sound Boost	-	-	-	-	-	-	-	-	-	-	-	-		
			Wall EQ	-	-	-	-	-	-	-	-	-	-	-	-		
			AUX Out Volume	-	-	-	-	-	-	-	-	-	-	-	-		
			Volume Limiter	-	-	-	-	-	-	-	-	-	-	-	-		
			AUX In Noise Gate	-	-	-	-	-	-	-	yes	yes	-	-	-	-	
	System	Version, Language, Manual, FAQ	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Audio Rec Format	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Auto Power Off	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Firmware Version, Firmware Update	-	-	-	-	-	-	yes	yes	-	-	-	-	-		
		Factory Reset	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Backup, Restore		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes			
Connection	Wi-Fi (*3)	UD-WL01	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes			
	Bluetooth (*2) (*3)	Built-in	-	-	-	-	yes	yes	-	yes	-	-	-	yes			
		UD-BT01 (for iPhone / iPad)	-	-	-	-	-	-	-	-	-	-	-	-			
	USB cable (for iPhone / iPad with Lightning terminal)	Lighting - USB cable	-	-	-	-	-	-	yes	-	-	-	-	-			
		Lightning to USB Camera Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	yes			
		Lightning to USB Camera Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-			
	USB cable (for iPhone / iPad with Type-C terminal)	USB-C - Lightning cable	-	-	-	-	-	-	-	-	-	-	-	-			
USB-C Digital AV Multipoint Adapter or USB-C VGA Multipoint Adapter + USB cable (Type A plug - Type B plug)		yes	yes	yes	yes	yes	yes	yes	-	yes	yes	yes	yes				
USB cable (for Android devices with Type-C Terminal)	USB-C Digital AV Multipoint Adapter or USB-C VGA Multipoint Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-				
	USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	yes	-	-	-	-				
	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	-	yes	yes	yes	yes				
USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-					
USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	yes	-	-	-	-					

(*1) Tempo can be changed while song is playing.

(*2) During Bluetooth connection, audio recording function is not available.

(*3) Availability varies by area.

Available functions for each instrument

Updated: 2024/4

Functions			ARIUS				P						Plaggero	Standalone	
			YDP-105	YDP-144 YDP-164 YDP-S34 YDP-S54	YDP-145 YDP-165 YDP-S35 YDP-S55	YDP-184	P-121 P-125 P-128	P-125a	P-143 P-145	P-223 P-225	P-515	P-525	P-S500	NP-15 NP-35	from installing the app to connecting a supported instrument
Piano Room	Piano Room	Lid Position	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Brightness	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
	Piano Room Setting	Touch Curve	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
		Environment	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		VRM	-	-	yes	yes	-	-	yes	yes	yes	yes	-	-	
		Damper Resonance	yes (on/off only)	yes (on/off only)	-	yes	yes (on/off only)	yes (on/off only)	yes (on/off only)	-	yes	yes	yes (on/off only)	-	
		Damper Noise	-	-	-	-	-	-	-	-	yes	-	-	-	
		String Resonance	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
		Duplex Scale Resonance	-	-	-	yes	-	-	-	yes	yes	-	-	-	
		Body Resonance	-	-	-	yes	-	-	-	yes	yes	-	-	-	
		Grand Expression Modeling	-	-	-	-	-	-	-	-	yes	-	-	-	
		Key Off Sampling	-	-	-	yes	-	-	-	yes	-	yes	-	-	
		Half Pedal Point	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
Each Key Setting	-	yes	yes	yes	yes	-	-	yes	yes	yes	yes	-			
Voice	Voice Select	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Layer	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Left, Split Point	-	-	-	yes	yes	yes	-	yes	yes	yes	-	-		
	Voice Setting	Octave	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
Mixer		Volume	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		Pan	-	-	-	yes	-	-	-	yes	yes	yes	-		
Reverb	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
Style		-	-	-	-	-	-	-	-	-	yes	-	-		
Song	Playback, FF, Rewind	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song - Preset)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		(MIDI Song - User)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-	
	AB Repeat	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
	Guide (MIDI Song)	(Audio Song)	-	-	-	-	-	-	-	-	-	yes	-	-	
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Volume	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Tempo	(Audio Song)	yes (*1)	yes (*1)	yes (*1)	yes	yes (*1)	yes (*1)	yes (*1)	yes	yes	yes	yes (*1)	-	
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Transpose	(Audio Song)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-	
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Part (MIDI Song)	Right, Left	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Backing	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
	PDF Score	Viewer	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Playback	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	yes	
		Guide	-	-	-	-	-	-	-	-	-	yes	-	-	
	Score Screen	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Chord Screen	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Lyrics Screen	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Audio Song Analysis	Audio to Score	-	-	-	-	-	-	-	-	-	-	yes	-	
		Chord Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Chord Edit	Copy, Delete, Undo	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Audio to Score Setting	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Song Setting	Arrangement (Audio Song)	Backing	-	-	-	-	-	-	-	-	-	yes	-	
			Melody Suppressor	-	-	-	-	-	-	-	-	-	yes	-	
Stream Lights / Guide Lamp			-	-	-	-	-	-	-	-	-	(Stream Lightes)	-		
Playback		Guide Type (MIDI Song)	-	-	-	-	-	-	-	-	-	yes	-		
		Quick Start (MIDI Song)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-		
		MIDI Part Channel (MIDI Song)	-	-	-	-	-	-	-	-	-	yes	-		
		Score	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Chord		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Lyrics		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Mixer		-	-	-	-	-	-	-	-	-	yes	-	-		
Song Edit	Quantize (MIDI Song)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-		
	Delete, Mix, Setup (MIDI Song)	-	-	-	-	-	-	-	-	-	yes	-	-		
	Trimming (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Recording	Audio Recording (*2)	yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	-		
	Audio Overdub Recording (*2)	yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	-		
	MIDI Recording	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-		
	MIDI Multitrack Recording	-	-	-	-	-	-	-	-	-	yes	-	-		
Metronome	Metronome	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Rhythm	-	-	-	yes	yes	yes	-	yes	yes	yes	-	-		
Bass On/Off	-	-	-	-	yes	yes	-	yes	yes	yes	-	-			
Balance	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Registration Memory	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Utility	Transpose	Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Scale Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Keyboard Setting	Touch Curve	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
		TRS	-	-	-	-	-	-	-	-	-	-	-	-	
	Pedal Setting	Function Assign	-	-	-	-	-	-	-	-	-	yes	-	-	
		Score Page Turning	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-	
		Half Pedal Point	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
	AUX Pedal Polarity	-	-	-	-	-	-	-	yes	yes	yes	-	-		
	Mic Setting	Vocal Harmony	-	-	-	-	-	-	-	-	-	yes	-	-	
		Master EQ	-	-	-	-	-	-	-	-	-	yes	-	-	
	Sound Setting	Brilliance	Speaker Setting	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	
			Stereophonic Optimizer	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	
			Binaural / Stereophonic Optimizer	-	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	-	Stereophonic Optimizer	Binaural	Binaural	Binaural	-
			Lid Position / TA Mode Tone Control	-	-	-	-	-	-	-	-	-	-	-	-
			IAC (Intelligent Acoustic Control)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-
			Sound Boost	-	-	-	-	-	-	yes	yes	-	yes	-	-
			Wall EQ	-	-	-	-	-	-	-	yes	-	-	-	-
AUX Out Volume			-	-	-	-	-	-	-	yes	-	-	-	-	
Volume Limiter			yes	-	yes	-	-	-	-	-	-	-	-	-	
Limit Point			-	-	-	-	-	-	-	-	-	-	-	-	
AUX In Noise Gate	-	-	-	-	-	-	-	-	-	yes	-	-			
System	Version, Language, Manual, FAQ	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Audio Rec Format	yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	-		
	Auto Power Off	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Firmware Version, Firmware Update	-	-	-	-	-	-	-	-	-	-	yes	-		
	Factory Reset	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Backup, Restore	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
Demo	-	-	-	-	-	-	-	-	-	-	yes	-	-		
Connection	Wi-Fi (*3)	UD-WL01	-	-	-	yes	-	-	-	yes	yes	yes	-		
	Bluetooth (*2) (*3)	Built-in	-	-	-	-	-	-	-	-	yes	-	-		
		UD-BT01 (for iPhone / iPad)	-	-	-	-	-	-	yes	yes	-	-	yes		
	USB cable (for iPhone / iPad with Lightning terminal)	Lighting - USB cable	-	-	-	-	-	-	-	-	-	yes	-		
		Lightning to USB Camera Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes		
		Lighting to USB Camera Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	yes	-		
	USB cable (for iPhone / iPad with Type-C terminal)	USB-C - Lightning cable	-	-	-	-	-	-	-	-	-	-	-		
		USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes		
		USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-		
	USB cable (for Android devices with Type-C Terminal)	USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	-	yes	-	-		
USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type B plug)		yes	yes	yes	yes	yes	yes	yes	yes	-	yes	yes			
USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-			
USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	-	-	yes	-	-			

(*1) Tempo can be changed while song is playing.

(*2) During Bluetooth connection, audio recording function is not available.

(*3) Availability varies by area.